

Casey and his friends™ Instruction Manual

Follow these simple instructions to ensure safety.



Hold child safety buckle in one hand.



Properly secure the product by inserting buckle through opening at the rear of the Carsey™ toy.



Slide the Carsey™ toy downward to ensure buckle is completely exposed.



Once the Carsey™ has been inserted placed over the buckle, the shoulder safety straps are to be inserted downward; exactly the same way you would secure your car seat. If the Carsey™ toy is blocking closure of the buckle, child safety is in danger! Do not operate vehicle without proper closure!

